

9mm

8cm

8cm

SiNETAG

SiNE CARD II

User Manual



●Getting Started

- ① Make sure your phone's Bluetooth is ON and you are connected to the Internet.
- ② Ensure Location services are ON.
- ③ Open **Apple Find My** or **Google's Find Hub** app.
- ④ Log in with your account.

Note:


If Find Hub is not pre-installed on your Android™ device, then download it on Google Play.

●Power On

- ① Locate the button on the front of the SiNE CARD II.
- ② Press and hold the button for 3 seconds. The device beeps and flashes every second. Successful power-on is indicated by confirmation beeps and three flashes.

●Important Tips

- ① **To re-pair or change networks, it got to do the Factory Reset.**
- ② Upon powering on, the device will broadcast Apple and Google network signals simultaneously for pairing. If no pairing occurs within 10 minutes, the device will automatically power off.



●Connect to the Find My app

- ① Bring your device close to your iPhone and open Find My app. Tap the **Items** tab , tap **+** and then **Add Other Item**.
- ② Tap **Connect** to SiNE CARD II , and type a name, select an emoji.
- ③ Accept the prompts to complete the pairing.

●Connect to the Find Hub app

- ① Bring your device close to your phone and wait for the pop-up to show SiNE CARD II, on the pop-up bottom sheet, tap 'Connect'.
- ② Read and accept the prompts to complete the pairing.

●Sleep Mode (Locating Function is off)

Quickly press the button five times. A confirmation beep will sound, and the light will blink three times.

●Factory Reset

- ① Double-click the button; immediately press and hold after hearing the beep.
- ② Continue holding for over 5 seconds until a continuous ringing tone plays and the light flashes continuously.

●Status Check (Network & Battery)

While the device is on, double-click the button to check current information via the status indicator:

- ① **Pairing Status:** The indicator will first show the color corresponding to the current network.
- ② **Battery Level:** After one second, the indicator will switch to the battery level color for one second.

Category	LED Color	Status Description
Network Status	Blue	Connected to Find My network
	Green	Connected to Find Hub network
	Red	Network not selected
Battery Level	Green	100% - 80%
	Yellow	79% - 40%
	Orange	39% - 10%
	Red	9% - 0%

●Battery Charging

- ① Connect the charger
- Place the SiNE CARD II on a standard wireless charger.
- ② Check the charging indicator light
 - Red light: Charging in progress
 - Green light: Fully charged
- ③ Make sure the indicator light turns on during charging.
- If the light does not turn on, reposition the SiNE CARD II on the wireless charger.

●Battery Information and Warning

- This device uses a built-in, non-removable lithium-ion battery.
- Battery capacity : 155mAh
- Failure to follow the guidelines below may shorten the lifespan of the lithium-ion rechargeable battery inside the device.
- Do not disassemble, puncture, or damage this device.
- Do not expose this device to flames, explosions, or other hazards.
- Do not remove or attempt to remove the internal battery that is not user-replaceable.
- Use your device at normal operating temperatures (~20°C to 60°C or ~4°F to 140°F).

●NFC Tag

- SiNE CARD II supports NFC (13.56 MHz) with two customizable NDEF data profiles. Use a compatible NFC writing app to store a website link, text, or contact information in either profile.
- First profile: This is the default profile. Hold the card near your phone's NFC antenna to read or write. No button press is needed.
- Second profile: Quickly press the button twice, then hold the card near your phone's NFC antenna to read or write. The card automatically returns to the first profile after 3 minutes.
- Writing or erasing standard NDEF content in either profile does not affect the card's product authenticity verification function.
- Keep the card near your phone's NFC antenna until reading or writing is complete. The antenna location varies by phone model. Enable NFC if required. Some content may require a compatible app to read.

■ Depending on the market, one or both profiles may come preloaded with content, such as a website or a link to the user guide. You can keep, replace, or erase this content using a compatible NFC writing app.

FCC Statement

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - ① This device may not cause harmful interference.
 - ② This device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- 2. This device has been tested and complies with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

- 3. If this device does indeed cause harmful interference to radio or television reception, which can be determined by turning the device on and off, users are encouraged to try to correct the interference by one or more of the following measures:
 - ① Reorient or relocate the receiving antenna.
 - ② Increase the separation between the equipment and receiver.
 - ③ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - ④ Consult the dealer or an experienced radio/TV technician for help.
- 4. This device has been evaluated and found to meet general RF exposure requirements.
- 5. This device may be used under portable exposure conditions without restriction.

FCC ID: 2BEM5-SINECARDII



SiNETAG

SiNE CARD II User Manual

Ver 1.7